

Subfloor Construction	Binding Material according to EN 13813	Type of subfloor	R770	R777/R778	R844	R845	R850/R850T	R860	R870T	D705	D710	D720
Floating Screed including calcium sulphate screed also with underfloor heating system and Self Levelling compounds	CT	Cementitious -(heated)- Screed	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	CA	Calcium Sulfate -(heated)- Screed	✓	✓	✓	✓	✓	✓	✓	-	-	-
	CA	Calciumsulfate floating screed	✓	✓	✓	✓	✓	✓	✓	-	-	-
	AS	Mastic Asphalt, Well sanded**	✓	✓	✓	✓	✓	✓	✓	-	-	-
	CT/CA	Self Levelling Compounds	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Wooden Substrate		Chipboard, OSB, Plywood	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

* Whether you use a fine or a course trowel depends on the condition of the subfloor and the dimensions of the parquet elements

** For the usage of Bona´s silan based adhesives a protection primer like R540 or Bona R410 is necessary prior to the installation of the parquet