

Bona R845

Technical data sheet

R845 is an elastic; according to EN 14293 (soft); 1-component silane based adhesive for dimensional stable multilayered, engineered parquet. Tensions to the sub floor are reduced. The use of a primer is in general not necessary. The adhesive hardens by a chemical reaction with moisture.

- 1-component, easy to handle
- Soft elastic
- Water and solvent free, nearly no swelling of the wood
- Good adhesion to almost all substrates and timber materials, splashed material can be easily removed
- Firm texture – retains trowel pattern
- Rapid initial bonding strength

Technical data


Base:	Silane modified-Prepolymere
Colour:	Grey
Viscosity:	Easy to apply - stable
Density:	1.6 g/cm ³
GISCODE:	RS 10
Cleaning agent:	Bona S100, acetone and ethanol. Hardened adhesive can only be moved mechanically.
Application of load:	24 to 48 h
Surface treatment:	Depending on air humidity and the moisture content of the materials between 2 and 4 days.
Storage / transport:	The temperature must not fall below +5°C or exceed +25°C during storage and transport. Store in a cool, dry and well ventilated place
Shelf life:	12 months.
Pack size:	24 kg (32 per pallet)and 15 kg (44 per pallet)

Preparations

The substrate must in general be even, totally dry, clean, free from cracks and physically sound. The surface should also be slightly textured. If applicable, it must meet the requirements of local standards or codes of practice. If necessary it should be professionally prepared for laying. A primer is typically not needed, if the sub floor is problematic (e.g. weak surface, missing damp proof membrane) use Bona R410, Bona R540 or Bona R580. Broadcasting of sand into R410 can be omitted, if the surface of R410 stays clean and the parquet is glued with R845 within 24 h. Uneven floors should be levelled with H600 and H610 (filling of holes). Suitable substrates (also in association with underfloor heating) are:

- Cementitious screed (CT) according to EN 13813
- Floors levelled with levelling compounds (at least 2 mm thick), resistant against plasticizer migration
- Calcium sulfate screed (CA) according to EN 13813
- Chipboard (V100)
- Other dry and sound sub-floors
- Mastic asphalt screed (AS) according to EN 13813 and other sub floors which are affected by migration of plasticizers must get a protective layer of R410 or R540.

Fastening



Bona R845

Technical data sheet

Fastening



Application

Before using the adhesive the following climatic conditions must be met (values for Central Europe):

Air temperature: min. 18°C

Floor temperature: min. 15°C (with underfloor heating max. 20 °C)

R.H: max. 70 %

The adhesive itself must, if necessary, be brought to the right temperature. After opening the bucket remove the protective foil and hardend adhesive at the edges. The adhesive should be applied evenly using a notched trowel appropriate to the flooring being laid (see below). The parquet should be laid on the adhesive and pressed down firmly during the open time, approx. 30 minutes. If on the sub floor applied adhesive has a skin, remove adhesive and apply new. If some adhesive is pressed up in joints (so that it might come into direct contact with the finish) it must be carefully removed (danger of migration of plasticizers in the finish film).

After 24 to 48 hours it is possible to apply load or stress to the floor. Sanding and the application of a surface coating may be carried out after 2 to 4 days depending on the type of parquet, absorbency of the substrate and room climate.

Consumption/parquet types

Depending on the expected average conditions the parquet needs, for the best adhesion, the correct moisture content of the wood to be selected. Solid wood parquet should be slightly more humid whilst multi-layered or prefinished parquet should be slightly drier. E.g. in Central Europe average room conditions of 20°C and 50 % relative air humidity can be expected. Prefinished parquet shall have in average 8 %. Typical deviations from the average are +/- 2 %. Where doubts exist, avoid too dry material. Please also refer to the instructions for use provided by the parquet manufacturer.

Bona 1000 F or Bona 1000 G

Usage: approximately 1100 g/m²:

- 2 layered prefinished parquet

Bona 1250 F or Bona 1250 G

Usage: approximately 1350 g/m²:

- 3 layered prefinished parquet, boards

Use a fine trowel for small pieces of wood and/or smooth substrates, and a coarse trowel for large pieces of wood and/or less smooth and rough surfaces.

(F = fine, G = coarse)

Other details of the product are described in an additional data sheet.

Bona takes only responsibility for the delivered product, no responsibility can be taken for the total installed product. If in doubt, conduct a test or a trial. Observe also other Bona product datasheets.